

# IntegraAdhesives

## Purging new & previously used cartridges



OR > Take the cap or old mixing-tip off of the cartridge.



+ > Put the cartridge in a dispenser, point the top upwards (not down into a waste-bin), and without mixing-tip applied push out adhesive until you have released all air from the cartridge & have seen both components flowing out correctly.

The activator should be a semi-transparent & liquid-smooth substance, not yellow or rubbery.



+ > Wipe away excess adhesive, and apply a mixing-tip.



+ > Dispense adhesive and throw away the first little bit, the cartridge is now ready for use. If while construction the cartridge is not used for a while, replace the mixing-tip first before continuing.



> After use, leave the mixing-tip on the tube & store away upright for future use.